



INDUSTRIES

DISSENT



1. This installation assumes there is no current stock installed on the firearm. If there is, please remove stock and buffer tube.
2. Thread in the supplied buffer adapter as shown below. NOTE: the adapter should be threaded below the face of the receiver approximately 1/16".
3. Insert your rear takedown pin, detent pin, and spring as shown.



INSTALLATION

1. Line up the brace/stock adapter and press it up against the back of the receiver, compressing the detent spring. Take care not to pinch the spring.
2. With the stock braced against the table as shown, hold the stock and receiver together while inserting the supplied washer as shown.



1. Apply Loctite to the threads of the provided 1/4" x 1" Torx screw.
2. Using an 1/8" Allen wrench, tighten the screw until tight, locking the HDA3 adapter to the receiver.
3. Installation is now complete.



ALL NFA RULES APPLY. It is up to the user to ensure that installing this product does not violate any rules set forth by BATF concerning NFA requirements.