



BERETTA DIRECT-FIT STOCK/BRACE INSTALLATION

NOTE: Never work on a loaded firearm. Before beginning the installation remove the magazine and clear the chamber.

INSTALLATION:

1. To begin installing your A3 Tactical Direct-fit stock, the factory rear back plate must first be removed. This is accomplished by driving out the factory installed roll pin using a 3/16" diameter punch.
2. Slowly tap the pin out using the punch and a small hammer. The pin can be driven out from the top or bottom.
3. Once the pin is out, remove the factory end cap and insert the Direct-fit stock in its place. *NOTE: we intentionally made this a tight fit to provide tension when folded. It will take some effort to align the stock on the hinge.*
4. Once the Direct-fit stock is aligned, drive the pin through the pin bore. Again, this will be a tighter fit than the factory pin and will take more effort to seat the pin.
5. Once fully installed, test the latch button and fold the stock.

