



PWS UXR REAR 1913 ADAPTER

- Never work on a loaded firearm. Before proceeding, remove magazine and clear chamber. -

1. Locate the steel insert in the hardware packet. This insert protects the polymer rail on the receiver and is necessary to tighten the adapter to the receiver. Position the insert into the second slot from the top, as shown in the image below.
2. Holding the insert in place, slide the adapter down from the top until it bottoms out and is flush with the receiver.
3. Using a 5/64" Allen wrench, tighten the set screws on the rear of the adapter until snug.

